

* 0078-001-H102 (G\$DR)

DRAWING NO. 41285543-001-03

PAGE 1

0001
0002
0003
0004
0005
0006
0007
0008
0009
0010
0011
0012
0013
0014
0015
0016
0017
0018
0019
0020
0021
0022
0023
0024
0025
0026
0027
0028
0029
0030
0031
0032
0033
0034
0035
0036
0037

* 0078-001-H102 (G\$DR) DRAWING NO. 41285543-001-03

```
*
*
*
* COMPUTER:  H316, H516
*
*
* PROGRAM CATEGORY:  INPUT-OUTPUT
*
*
* PROGRAM TITLE:  G$DR
*                  GENERIC DUMMY ROUTINE
```

APPROVAL

DATE _____

PROG.

SUPR

QUAI

NO. OF PAGES

71

* 0078-001-H102 (G\$DR)

DRAWING NO. 41285543-001-03

PAGE 2

0038
0039
0040
0041
0042
0043
0044
0045
0046
0047
0048
0049
0050
0051
0052
0053
0054
0055
0056
0057
0058
0059
0060
0061
0062
0063
0064
0065
0066
0067
0068
0069
0070
0071
0072
0073
0074

```

*
*
*  AUTHOR
*
*      HONEYWELL INFORMATION SYSTEMS LTD.
*
*
*  PURPOSE
*
*      1      TO DETERMINE THE ADDRESS AND SIZE OF THE FREE CORE AREA
*              AVAILABLE TO THE CALLING PROGRAM FOR WORKSPACE, AND ENABLE
*              EXTENDED ADDRESSING IF APPROPRIATE.
*
*      2      TO SATISFY ANY OUTSTANDING CALLS ON INPUT-OUTPUT LIBRARY
*              ROUTINES, AND IGNORE OR ABORT ANY ATTEMPT TO USE THEM AT RUN
*              TIME.
*
*
*  RESTRICTIONS
*
*      THIS PROGRAM WILL WORK ON ANY H316 OR H516 COMPUTER, WITH UP TO
*      32 768 WORDS OF CORE STORE.  IT IS WRITTEN IN UNIVERSAL MODE,
*      I.E. IT WILL WORK EQUALLY WELL WHETHER EXTENDED ADDRESSING IS
*      ENABLED OR NOT (SEE 'USE' BELOW).
*
*      IF G$DR IS REQUIRED FOR PURPOSE 1 ABOVE, IT MUST BE LOADED AFTER
*      ALL OTHER SUBROUTINES.  IN THIS CASE, CARE MUST BE TAKEN THAT
*      NEITHER WORD '42 NOR WORD '43 OF G$DR LIES IN THE FIRST LOCATION
*      OF A 4K MEMORY MODULE (I.E. IN LOCATION '10000, '20000, ETC.),
*      AS THIS WILL CAUSE A HALT ON THE FIRST G$DR CALL.  ALSO, FOR THIS
*      PURPOSE G$DR MUST NOT LIE IN SECTOR 0 OR SECTOR 1.
*
*      IT SHOULD ALSO BE NOTED THAT G$DR ALTERS THE CURRENT BASE SECTOR.
*
*
*  STORAGE
*
*

```

* 0078-001-H102 (G\$DR)

DRAWING NO. 41285543-001-03

PAGE 3

0075 * 56 (OCTAL)
0076 * 46 (DECIMAL)
0077 *
0078 * ALL BUT THE FIRST '26 (22) LOCATIONS ARE FREED WHEN G\$DR IS FIRST
0079 * CALLED. IF THE PROGRAM IS NOT REQUIRED FOR PURPOSE 1 ABOVE, THE
0080 * LAST '30 (24) LOCATIONS MAY BE OVERWRITTEN AT LOAD-TIME.
0081 *
0082 *
0083 * TIMING
0084 *
0085 * G\$DR: 11 CORE STORE CYCLES (EXCEPT THE FIRST TIME IT IS CALLED)
0086 * TABS ENTRIES: 16 CYCLES
0087 * SKP ENTRIES: 8 CYCLES
0088 * NOP ENTRIES: 5 CYCLES
0089 * ERNA ENTRIES: NOT APPLICABLE
0090 * INCLUDING THE CALL, ASSUMING NO DESECTORING TO BE NECESSARY.
0091 *
0092 *
0093 * USE
0094 *
0095 * LOADING PROCEDURE
0096 *
0097 * EXACT DETAILS CANNOT BE GIVEN HERE, BUT THE FOLLOWING
0098 * OBJECT MODULES SHOULD BE LOADED, IN ORDER, USING LDR-APM OR A
0099 * SIMILAR LOADER, FOR A TYPICAL CASE:
0100 *
0101 * 1 MAIN PROGRAM (USUALLY STARTING AT '1000)
0102 *
0103 * 2 APPROPRIATE INPUT-OUTPUT SUPERVISOR
0104 *
0105 * 3 AS MANY INDIVIDUAL INPUT-OUTPUT LIBRARY ROUTINES AS
0106 * REQUIRED, DEPENDING ON THE HARDWARE OPTIONS AVAILABLE
0107 *
0108 * 4 G\$DR
0109 *
0110 * G\$DR MUST BE LOADED LAST, AS IT ASSUMES THAT THE REST OF THE
0111 * CORE STORE (STARTING AT LOCATION G\$FF (FIRST FREE LOCATION))

* 0078-001-H102 (G\$DR)

DRAWING NO. 41285543-001-03

PAGE 4

0112 * CAN BE USED BY THE CALLING PROGRAM AS WORKSPACE AT RUN TIME.
0113 *
0114 * CARE SHOULD BE TAKEN TO SELECT THE CORRECT DESECTORING MODE.
0115 * IF THE PROGRAM IS TO WORK ON COMPUTERS HAVING NOT MORE THAN
0116 * 16 384 WORDS OF CORE STORE, OR IF ANY ONE OR MORE OF THE
0117 * CONSTITUENT MODULES IS RESTRICTED TO 16K WORKING BY, FOR
0118 * EXAMPLE, SIMULTANEOUS USE OF INDEXING AND INDIRECT, THEN ALL
0119 * LOADING SHOULD BE CARRIED OUT IN LXD MODE, E.G. BY ENTERING
0120 * LDR-APM AT 'XX000. CONVERSELY, IF THE PROGRAM WILL ONLY BE
0121 * USED ON COMPUTERS WITH MORE THAN 16 384 WORDS OF CORE STORE,
0122 * AND ALL MODULES ARE WRITTEN IN UNIVERSAL MODE, THE LOADING
0123 * MAY BE CARRIED OUT IN EXD MODE, E.G. BY ENTERING LDR-APM AT
0124 * 'XX006.
0125 *
0126 * IF DESECTORING IN THE CURRENT BASE SECTOR IS TO BE AVOIDED,
0127 * DO NOT LOAD G\$DR ACROSS A SECTOR BOUNDARY.
0128 *
0129 *
0130 * GENERIC DUMMY ROUTINE
0131 *
0132 * THIS ENTRY MAY BE USED BY AN INPUT-OUTPUT SUPERVISOR PROGRAM
0133 * TO DETERMINE THE ADDRESS AND SIZE OF THE FREE CORE AREA
0134 * AVAILABLE FOR USE AS WORKSPACE, SUCH AS A COMPILER SYMBOL
0135 * TABLE. THE CALLING SEQUENCE IS:
0136 *
0137 * CALL G\$DR
0138 *
0139 * GENERIC DUMMY ROUTINE
0140 * NORMAL RETURN, WITH THE A-
0141 * REGISTER CONTAINING THE
0142 * ADDRESS OF THE FIRST FREE
0143 * LOCATION, AND THE X-REGISTER
0144 * CONTAINING MINUS THE NUMBER OF
0145 * FREE LOCATIONS UP TO THE TOP
0146 * OF MEMORY ACTUALLY AVAILABLE
0147 * IN THE OBJECT COMPUTER.
0148 * EXTENDED ADDRESSING WILL HAVE
* BEEN ENABLED OR DISABLED.

* 0078-001-H102 (G\$DR)

DRAWING NO. 41285543-001-03

PAGE 7

0223	SUBR	O\$AH,SKP	ASR HEADING ROUTINE
0224	SUBR	O\$AL,ERNA	ASR LISTING ROUTINE
0225	SUBR	O\$HH,SKP	ASR LIST HEADING
0226	SUBR	O\$LL,ERNA	ASR LIST
0227	SUBR	O\$AE,NOP	ASR LIST EJECT PAGE
0228	SUBR	O\$AP,ERNA	ASR PRINT ROUTINE
0229	*		
0230	SUBR	I\$PI,TABS	INITIALISE SOURCE HSR
0231	SUBR	I\$PIE,TABS	INITIALISE SOURCE HSR
0232	SUBR	I\$PA,ERNA	HSR INPUT SOURCE RECORD
0233	SUBR	I\$PAE,ERNA	HSR INPUT SOURCE RECORD
0234	SUBR	I\$PB,ERNA	HSR INPUT OBJECT LINK
0235	SUBR	I\$PO,ERNA	HSR INPUT OBJECT
0236	*		
0237	SUBR	O\$PI,TABS	INITIALISE SOURCE HSP
0238	SUBR	O\$PIE,TABS	INITIALISE SOURCE HSP
0239	SUBR	O\$PA,ERNA	HSP OUTPUT SOURCE RECORD
0240	SUBR	O\$PAE,ERNA	HSP OUTPUT SOURCE RECORD
0241	SUBR	O\$PS,NOP	HSP OUTPUT END OF TEXT
0242	SUBR	O\$PSE,NOP	HSP OUTPUT SOURCE END OF TEXT
0243	SUBR	O\$PSS,NOP	HSP OUTPUT SOURCE END OF TEXT
0244	SUBR	O\$PC,NOP	HSP OUTPUT CARRIAGE RETURN
0245	SUBR	O\$PF,NOP	HSP OUTPUT LINE FEED
0246	SUBR	O\$PLDR,NOP	HSP PUNCH LEADER
0247	SUBR	O\$POFF,NOP	HSP OFF
0248	SUBR	O\$PB,ERNA	HSP OUTPUT OBJECT LINK
0249	SUBR	O\$PO,ERNA	HSP OUTPUT OBJECT
0250	SUBR	O\$PSO,NOP	HSP OUTPUT OBJECT END OF TEXT
0251	SUBR	O\$PH,SKP	HSP LIST HEADING
0252	SUBR	O\$PL,ERNA	HSP LIST
0253	SUBR	O\$PE,NOP	HSP LIST EJECT PAGE
0254	SUBR	O\$PP,ERNA	HSP PRINT ROUTINE
0255	*		
0256	SUBR	I\$CA,ERNA	CARD READER INPUT SOURCE RECORD
0257	SUBR	I\$CABL,NOP	CARD READER SOURCE INPUT BUFFER LENGTH
0258	SUBR	I\$CO,NOP	CARD READER OFFSET STACK CARD
0259	SUBR	I\$CB,ERNA	CARD READER INPUT OBJECT LINK

* 0078-001-H102 (G\$DR)

DRAWING NO. 41285543-001-03

PAGE 8

0260	SUBR	I\$CBO,ERNA	CARD READER INPUT OBJECT
0261	*		
0262	SUBR	O\$CA,ERNA	CARD READER OUTPUT SOURCE RECORD
0263	SUBR	O\$CABL,NOP	CARD PUNCH SOURCE OUTPUT BUFFER LENGTH
0264	SUBR	O\$CO,NOP	CARD PUNCH OFFSET STACK CARD
0265	SUBR	O\$CS,NOP	CARD PUNCH OUTPUT END OF TEXT
0266	SUBR	O\$CSS,NOP	CARD PUNCH OUTPUT SOURCE END OF TEXT
0267	SUBR	O\$CB,ERNA	CARD PUNCH OUTPUT OBJECT LINK
0268	SUBR	O\$CBO,ERNA	CARD PUNCH OUTPUT OBJECT
0269	*		
0270	SUBR	O\$LH,SKP	LINE PRINTER LIST HEADING
0271	SUBR	O\$LA,ERNA	LINE PRINTER LIST LINE
0272	SUBR	O\$LE,NOP	LINE PRINTER LIST EJECT PAGE
0273	SUBR	O\$LF,NOP	LINE PRINTER ADVANCE ONE LINE
0274	SUBR	O\$LO,ERNA	LINE PRINTER PRINT ONE LINE
0275	SUBR	O\$LP,NOP	LINE PRINTER ADVANCE TO TOP OF FORM
0276	*		
0277	SUBR	I\$MA,ERNA	READ MAGNETIC TAPE BCD
0278	SUBR	I\$MB,ERNA	READ MAGNETIC TAPE BINARY, 2 CH/WORD
0279	SUBR	I\$MC,ERNA	READ MAGNETIC TAPE BINARY, 3 CH/WORD
0280	*		
0281	SUBR	O\$MA,ERNA	WRITE MAGNETIC TAPE BCD
0282	SUBR	O\$MB,ERNA	WRITE MAGNETIC TAPE BINARY, 2 CH/WORD
0283	SUBR	O\$MC,ERNA	WRITE MAGNETIC TAPE BINARY, 3 CH/WORD
0284	SUBR	O\$ME,SKP	MAGNETIC TAPE WRITE FILE MARK
0285	*		
0286	SUBR	M\$UNIT,NOP	MAGNETIC TAPE UNIT NUMBER ROUTINE
0287	SUBR	C\$MR,SKP	MAGNETIC TAPE REWIND
0288	SUBR	C\$FR,ERNA	MAGNETIC TAPE FORWARD ONE RECORD
0289	SUBR	C\$BR,ERNA	MAGNETIC TAPE BACKSPACE ONE RECORD
0290	SUBR	C\$FF,ERNA	MAGNETIC TAPE FORWARD ONE FILE MARK
0291	SUBR	C\$BF,ERNA	MAGNETIC TAPE BACKSPACE ONE FILE MARK
0292	*		
0293	SUBR	C\$6TO8,ERNA	CONVERT FROM SIX-BIT CODE TO ISO CODE
0294	SUBR	C\$8TO6,ERNA	CONVERT FROM ISO CODE TO SIX-BIT CODE
0295	SUBR	C\$IS,ERNA	CONVERT FROM INVISIBLE TO SIX-BIT CODE
0296	SUBR	C\$SI,ERNA	CONVERT FROM SIX-BIT CODE TO INVISIBLE CODE

* 0078-001-H102 (G\$DR)

DRAWING NO. 41285543-001-03

PAGE 9

```
0297          SUBR C$IN,TABS          INITIALISE SOURCE
0298          *
0299          SUBR G$FF                FIRST FREE LOCATION
0300          *
0301          *
0302          CF5                      H316 OR DDP-516
0303          REL                      RELOCATABLE
0304          *
0305          *
0306          * GENERIC DUMMY ROUTINE
0307          *
0308 00000 0 000000 G$DR DAC **      GENERIC DUMMY ROUTINE
0309          *
0310          * THE NEXT INSTRUCTION IS CHANGED, ON FIRST ENTRY, TO EITHER DXA OR EXA
0311 00001 0 01 00026 MODE JMP DCS    DETERMINE CORE SIZE
0312 00002 0 02 00024 LDA AFFL      ADDRESS OF FIRST FREE LOCATION
0313 00003 0 35 00025 LDX MNFL     MINUS NUMBER OF FREE LOCATIONS
0314 00004 -0 01 00000 JMP* G$DR    EXIT
0315          *
0316          *
0317          * DEFAULT INPUT-OUTPUT ROUTINES
0318          *
0319          * IGNORE BUFFER SIZE, NUMBER OF TABS, AND TAB TABLE
0320 00005 0 000000 TABS DAC **      IGNORE BUFFER SIZE AND TABS
0321 00006 0 12 00005 IRS TABS      TALLY RETURN ADDRESS (IGNORE BUFFER SIZE)
0322 00007 -0 02 00005 LDA* TABS    NUMBER OF TABS (N)
0323 00010 0 06 00005 ADD TABS      ADD (N+1) TO RETURN ADDRESS
0324 00011 141206 AOA
0325 00012 0 04 00005 STA TABS      RETURN ADDRESS
0326 00013 -0 01 00005 JMP* TABS  EXIT
0327          *
0328          * IGNORE HEADING ADDRESS (OR LOGICAL UNIT NUMBER)
0329 00014 0 000000 SKP DAC **      IGNORE HEADING ADDRESS
0330 00015 0 12 00014 IRS SKP      TALLY RETURN ADDRESS (IGNORE HEADING ADDR)
0331 00016 -0 01 00014 JMP* SKP    EXIT
0332          *
0333          * IGNORE CALL WITHOUT PARAMETERS
```

* 0078-001-H102 (G\$DR)

DRAWING NO. 41285543-001-03

PAGE 10

```
0334 00017 0 000000 NOP DAC **      IGNORE CALL WITHOUT PARAMETERS
0335 00020 -0 01 00017 JMP* NOP      EXIT
0336          *
0337          * ERROR: DEVICE NOT AVAILABLE
0338 00021 0 000000 ERNA DAC **      ERROR: DEVICE NOT AVAILABLE
0339 00022 -0 10 00023 JST* G$NA    DEVICE NOT AVAILABLE ERROR ROUTINE
0340          *
0341          *
0342          * CONSTANTS AND VARIABLES 1
0343          *
0344 00023 0 000000 G$NA XAC G$NA    DEVICE NOT AVAILABLE ERROR ROUTINE
0345 00024 0 000026 AFFL DAC G$FF    ADDRESS OF FIRST FREE LOCATION
0346 00025 MNFL BSS 1              MINUS NUMBER OF FREE LOCATIONS
0347          *
0348          *
0349          * FIRST FREE LOCATION (FROM HERE UPWARDS MAY BE OVERWRITTEN)
0350          *
0351 00026 G$FF BSS 0              FIRST FREE LOCATION
0352          *
0353          *
0354          * DETERMINE CORE SIZE (THIS CODE IS EXECUTED ONLY ONCE)
0355          *
0356 00026 0 02 00055 DCS LDA IPZE    INDEXED PZE INSTRUCTION
0357 00027 0414 76 LGL 2            TAG BIT TO C
0358 00030 0 02 00052 LDA DXA      DXA INSTRUCTION
0359 00031 100001 SRC              CONVERT TO EXA INSTRUCTION....
0360 00032 0 06 00035 ADD TWO      ..IF PROGRAM DESECTORED IN EXD MODE
0361 00033 0 04 00001 STA MODE     SET ADDRESSING MODE INSTRUCTION
0362 00034 0 04 00035 STA **1
0363 00035 000002 TWO DEC 2        OVERWRITTEN BY MODE INSTRUCTION
0364          *
0365          * CALCULATE CORE SIZE
0366 00036 140040 CRA
0367 00037 0 06 00053 CLCS ADD 4K    MEMORY MODULE SIZE
0368 00040 0 04 00025 STA CS       UPDATE CORE SIZE
0369 00041 -0 13 00025 IMA* CS     WRITE NON-ZERO WORD
0370 00042 0 35 00054 LDX ZERO     CLEAR INDEX IN CASE OF WRAP-AROUND WRITE
```

* 0078-001-H102 (G\$DR)

DRAWING NO. 41285543-001-03

PAGE 11

```
0371 00043 -0 13 00025 IMA* CS ATTEMPT TO RETRIEVE NON-ZERO WORD
0372 00044 100040 SIZE WORD LOST - CORE SIZE FOUND
0373 00045 0 01 00037 JMP CLCS WORD PRESERVED - TRY LARGER CORE SIZE
0374
0375 *
0376 00046 0 02 00024 * CORE SIZE FOUND LDA AFFL ADDRESS OF FIRST FREE LOCATION
0377 00047 0 07 00025 SUB CS CORE SIZE
0378 00050 0 04 00025 STA MNFL MINUS NUMBER OF FREE LOCATIONS
0379 00051 0 01 00001 JMP MODE GO LOAD REGISTERS AND EXIT
0380
0381 *
0382 *
0383 * CONSTANTS AND VARIABLES 2 (MAY BE OVERWRITTEN)
0384 00052 000011 DXA DXA DISABLE EXTENDED ADDRESSING
0385 00053 010000 4K OCT 10000 MEMORY MODULE SIZE
0386 00054 000000 ZERO OCT 0 ZERO
0387 *
0388 000025 CS EQU MNFL CORE SIZE
0389 000025 BASE EQU MNFL SPACE TO DESECTOR IPZE INSTRUCTION BELOW
0390 *
0391 * SET BASE SECTOR
0392 SETB BASE
0393 00055 1 00 01000 IPZE PZE *1000.1 INDEXED PZE INSTRUCTION
0394 *
0395 *
0396 END END OF G$DR 04.MAR.71 G.STUARTSON LITTLE

4K 000053 AFFL 000024 BASE 000025 CLCS 000037
CS 000025 DCS 000026 DXA 000052 ERNA 000021
G$DR 000000 G$FF 000026 G$NA 000023 IPZE 000055
MNFL 000025 MODE 000001 NOP 000017 SKP 000014
TABS 000005 TWO 000035 ZERO 000054
```

0000 WARNING OR ERROR FLAGS

\$DA 41285326-002-03 8.1.71 JDC